

# Yo-Yo sensing level measurement

## continuous level indication for bulk solids

**LF**


# Instruction for parameterisation

| S/N | serial number |
|-----|---------------|
|     |               |

| silo number / silo name |
|-------------------------|
|                         |

| Index   | Page |
|---|------|
| Display and input keys   Key functions   Menu levels   Numerical entry and text input ..... | 02   |
| LF20 first switch-on   Hardware locking mechanism .....                                     | 03   |
| LF20 parameterise .....   | 04   |
| Basic setup .....   | 05   |
| Signal inputs .....   | 06   |
| Relay output 1 and 2 .....  | 07   |
| Relay output 3 and 4 .....  | 08   |
| Relay output - Pulse settings - Reset pulse .....   | 09   |
| Measurement parameters .....  | 10   |
| Measurement parameters .....  | 11   |
| Manual mode .....   | 12   |
| Simulation .....  | 13   |
| Current output .....  | 14   |
| Output on alarm .....   | 15   |
| Safety distance .....   | 16   |
| Security distance .....   | 17   |
| Linearisation .....   | 18   |
| Display .....   | 19   |
| Diagnostics .....   | 20   |
| Error messages .....  | 21   |
| System parameters .....   | 22   |

## Display and input keys



## Key functions


| Key(s) | Function   |
|--------|--|
|        | - Downwards navigation in the <b>selection list</b><br>- Edit the numerical values within a function                         |
|        | - Upwards navigation in the <b>selection list</b><br>- Edit the numerical values within a function                           |
|        | - Navigation to the right within the group selection<br>- Downwards navigation within the parameter groups<br>- Confirmation |
|        | - Navigation to the left within the group selection<br>- Upwards navigation within the parameter groups                      |
|        | - Increases the contrast of the display  |
|        | - Decreases the contrast of the display  |
|        | - Starts measurement process<br>in case display shows <b>measured value [000]</b>  |
|        |  |

## Menu levels

Menu consists of two levels.


1. The level of the **parameter groups PG**  
These divide the menu into groups.
2. The level of the **parameters P**  
Here parameters can be selected or numerical values can be insert and stored.

In order to provide a improved orientation for each parameter a number is shown in the display and in this instruction.




## Numerical entry and text input

Select parameter display e.g. full calibration [003].



| Key(s) | Operation  |
|--------|--|
|        | 1. Pressure on one of these keys puts the blinking input mask on the first position.         |
|        | 2. Select with the keys the required sign.   |
|        | 3. Pressing the key puts the blinking input mask on the next position.                       |
|        | 4. Repeat step 2. and 3. until the value is completely inserted or changed.                  |
|        | 5. In case $\Rightarrow$ appears in the input mask the value is stored by pressing this key. |
|        | 6. Pressing both keys at the same time interrupts insert procedure. The edit mode is left.   |

## LF20 first switch-on



Initialization

Day of production

Type of device

Device version (hard- and software)

Order code (device configuration)

Please note selection.

Select language

Preset parameter English

060 Language

- |                                    |
|------------------------------------|
| <input type="checkbox"/> English   |
| <input type="checkbox"/> Deutsch   |
| <input type="checkbox"/> Français  |
| <input type="checkbox"/> Japanisch |

Select distance unit

Preset parameter m (meter)


083 distance unit

- |                             |
|-----------------------------|
| <input type="checkbox"/> m  |
| <input type="checkbox"/> ft |
| <input type="checkbox"/> in |

Last measurement value is shown.

A measuring procedure has to be operated in order to get an actual measuring value.

## Hardware locking mechanism




Disable parameterisation **- + + E** pressing at the same time

&-symbol is shown

Inputs no more possible.  
Measuring procedures can take place.

Deblock parameterisation **- + + E** pressing at the same time

## LF20 parameterise



Back from page  
LF-PA-05 to LF-PA-22

Move from measurement value indication to the group selection and choose the required parameter group [PG].

group selection 00+  
Jbasic setup  
PG 00+  
page LF-PA-05

► !!! At the time of the first start of operation and after any reset (see parameter [073]) the parameters in group basic setup [PG00] have to be inserted. \*)

Group selection 01+  
Jinputs and outputs  
PG 01+  
page LF-PA-06

Group selection 02+  
Jmeasurement param.  
PG 02+  
page LF-PA-10

Group selection 03+  
Jcurrent output  
PG 03+  
page LF-PA-14

Group selection 04+  
Jsafety setting  
PG 04+  
page LF-PA-15

Group selection 05+  
Jlinearization  
PG 05+  
page LF-PA-18

Group selection 06+  
Jdisplay  
PG 06+  
page LF-PA-19

Group selection 07+  
Jdiagnostics  
PG 07+  
page LF-PA-20

Group selection 08+  
Jsystem parameters  
PG 08+  
page LF-PA-22

Group selection 0D+  
service  
20

\*) In most cases this basic setup is sufficient for a successful start of operation.

► In addition for measurements are alternatively required (see page LF-PA06)


- selection of „start measurement“ for input 1 [010] or 2 [012] and wiring of the signal input accordingly
- for measurement type [020] the selection „periodical“.

► In order to protect sensing weight from spillage during filling process and quick discharging

- select „bolting“ for input 1 [010] or 2 [012] and wire the signal input accordingly (see page LF-PA06)

► Complex measurement tasks require further settings.

## Basic setup - parameter group PG 00+



Please see drawings below!

Please note setup values.

**Insert length:**  
Distance from flange bottom line to minimum fill level.

Default value      **length of measuring tape of LF20**

|                              |
|------------------------------|
| <b>001 empty calibration</b> |
| _____ m / ft / in            |

**Insert length:**  
Distance from flange bottom line to end of sensing weight.

Default value      **0.72 m**

|                           |
|---------------------------|
| <b>002 block distance</b> |
| _____ m / ft / in         |

**Insert length of measuring range:**  
Empty calibration [001] – block distance [002] –  $\geq 0.2$  m  
maximal empty calibration [001] – block distance [002] (bd)

Default value      **length of measuring tape – block distance**


|                             |
|-----------------------------|
| <b>003 full calibration</b> |
| _____ m / ft / in           |

Select measuring type (please see explanation below)

Default value      **single cycle**

|                                       |
|---------------------------------------|
| <b>020 measurement type</b>           |
| <input type="checkbox"/> single cycle |
| <input type="checkbox"/> periodical   |
| <input type="checkbox"/> manual       |

**Measuring information**  
Distance between flange bottom line and product  
Actual measuring value




### Measuring type Funktionen der Auswahl

- |              |  |                         |
|--------------|--|-------------------------|
| Single cycle | - Start by pressing <b>start-key</b> at LF20   | Discription<br>see page |
|              | - Start by <b>signal input 1 [010]</b> or <b>2 [012]</b>   | LF-PA-06                |
| Periodical   | - Start by time control of the LF20 depending on time interval in P [021] and time unit in P [022] | LF-PA-11                |
| Manual       | - Measurement cycles can be started with <b>man.start</b> key at the LF20.                         | LF-PA-12                |

In case the silo height is not known, the empty calibration can be determined by manual operation (see page LF-PA-12).

## Signal inputs - parameter group PG 01+



Please note selection.

Select function for input 1.

Default value      not used

010 input 1

- not used
- bolting
- start measurement

Select function for input 2.

Default value      not used

012 input 2

- not used
- bolting
- start measurement

**Input 1 [010] or 2 [012]** see LF-GI-08

Parameter      Function of input 1 or 2

**bolting**

If there is a signal at the input, the **LF20** is blocked for further measurements.

A running measurement is cancelled immediately.  
The sensing weight is moved into the upper limit position.

- Avoids e.g. spillage of the sensing weight during filling process.

**start measurement**

If there is a signal at the input, the **LF20** starts a new measurement.


- Can be used for the start by a key in a control room or by an external control.

► !!!

The external start key is connected to **input 1 [010]** in the device version with option 10.2 (external start key mounted at the **LF20**)

Default value with option 10.2      **start measurement**

## Relay output 1 and 2 - parameter group PG 01+



Please note selection.

Select function for relay output 1.  
(see below description of functions)  
Default value alarm

relay output 1 014  
Jcounter pulses P 015 page LF-PA-09

relay output 1 014  
Jreset pulse P 019 page LF-PA-09

P 016 or P 019 page LF-PA-09

014 relay output 1

- alarm
- service interval
- counter pulses
- reset pulse
- running up
- top position
- measuring

Select function for relay output 2.  
(see below description of functions)  
Default value service interval

relay output 2 01A  
Jcounter pulses P 015 page LF-PA-09

relay output 2 01A  
Jreset pulse P 019 page LF-PA-09

P 016 or P 019 page LF-PA-09

01A relay output 2


- alarm
- service interval
- counter pulses
- reset pulse
- running up
- top position
- measuring

### relay output 1 [014] or relay output 2 [01A]

| Function         | Relay switches   |
|------------------|--|
| alarm            | as soon as an error is detected.<br>(e.g. tape breakage or spillage of the sensing weight)   |
| service interval | when the value set in the service interval function [024] is reached.  |
| counter pulses   | at the pulse value set in parameter [015] and with the counter pulse length set in parameter [016].  |
| reset pulse      | at the reset pulse length set in parameter [019] before a new measurement starts.<br><br>This output can be used to reset an external counter. |
| running up       | when running up the sensing weight.  |
| top position     | as soon as the upper limit position of the sensing weight is reached (end of measurement).   |
| measuring        | during the entire measuring period.  |

## **Relay output 3 and 4 - parameter group PG 01 →**


Relay output 3 [01B] and relay output 4 [01C] are optional available.



**relay output 1 [014] or relay output 2 [01A]**

| Function                | Relay switches   |
|-------------------------|--|
| <b>alarm</b>            | as soon as an error is detected.<br>(e.g. tape breakage or spillage of the sensing weight)   |
| <b>service interval</b> | when the value set in the service interval function [024] is reached.  |
| <b>counter pulses</b>   | at the pulse value set in parameter [015] and with the counter pulse length set in parameter [016].  |
| <b>reset pulse</b>      | at the reset pulse length set in parameter [019] before a new measurement starts.<br><br>This output can be used to reset an external counter. |
| <b>running up</b>       | when running up the sensing weight.  |
| <b>top position</b>     | as soon as the upper limit position of the sensing weight is reached (end of measurement).   |
| <b>measuring</b>        | during the entire measuring period.  |

## Relay output - pulse settings - parameter P 015 - P 016



Please note setup values.

### Insert pulse weight.

Default value 1


Range of values 1 ... 20 (2,5 cm ... 50 cm)

015 pulse weight

Pulse value x 2,5 cm = Move distance of the measuring tape per pulse

### Example

Pulse value 8 (8x2,5 cm) issues a counting pulse every 0.2 m.



### Insert pulse length.

Default value 50 ms

Range of values depended on pulse values [015]

016 pulse length

ms

### Pulse value [015]

1 30 ms ... 100 ms


2 30 ms ... 250 ms

3 30 ms ... 400 ms

4 ... 20 30 ms ... 550 ms

### Range of pulse length [016]

## Relay output - reset pulse - parameter P 019



### Insert length of reset pulse.


Default value 300 ms

Range of values 30 ms ... 1000 ms

019 reset pulse

ms

## Measurement parameters - parameter group PG 02+



Please note selection.

### Select measurement type.

Default value single cycle

020 Measurement type

- Single cycle
- periodical

### Select operating type.

Default value normal

At the start of a measurement the sensing weight is lowered down to the product and pulled back to the upper limit position.

023 normal or short

- normal
- short

Please note setup values.

### Insert number of measurement cycles.

024 service interval

Default value 45000

Range of values 1 ... 90000

- The number of measurement cycles depends on the process environment. The value should be adjusted to the level of dirt and/or measuring tape condition.

The relay output service interval switches as soon as the insert value is reached. The display alternately shows present error and measuring value. In the measured value display the alert symbol ⚠ for error is blinking.




### Service interval counter

Range of values 0 ... 90000

The counter shows the number of measurement cycles.

- Reset counter to 0 after maintenance was executed.

## Measurement parameters - parameter **P 021 - P 022**



Please note setup values.


Insert time interval for measurement type periodical [020].

Default value 1 h (depending on time unit [022])

Range of values 1 ... 60

The minimum time interval ( $T_{\text{minute}}$ ) for the distance between the measurements is dependent on the ambient temperature ( $T_{\text{amb}}$ ) and the measurement range ( $MR_{\text{meter}}$ ) and must not be undercut in all measurement types.

► Please pay attention to this, otherwise malfunctions could occur!



022-MZ01.cdr


Select time unit for time interval [021].

Default value h

Range of values h  
min. (hours)  
min. (minutes)

| 022 time unit                         |
|---------------------------------------|
| <input checked="" type="checkbox"/> h |
| <input type="checkbox"/> min.         |

## Measurement parameters - parameter **P 028**



The **operating mode short** can considerably shorten the length of a measurement cycle.

Insert run up length for operating type short [023].

Default value 1 m

Range of values 1 ... (Full calibration [003] ./ 1)


| 028 run up length |
|-------------------|
| m / ft / in       |

At the start of a measurement the sensing weight is lowered down to the product and pulled back to the position that has been insert in the run up length [028], e.g. 1 m above product using the default value.

For readjustment the upper limit position is approached every 20 measurement cycles.

- In this operating type the sensing weight is not protected from spillage.
- Select bolting for input 1 or 2 (see LF-PA-06) and wire the signal input accordingly. (with an active input, sensing weight will be immediately moved into the upper limit position)
- The use of the relay output function counter pulse [015/016] makes no sense, as the sensing weight does not approach a defined point at the end of the measurement. (and therefore no defined distance)


## Manual mode - parameter P 020



**Measurement type**  
Select manual.

Return to display **measured value [000]**.  
Manual measurements will be possible only, if the display shows **measured value [000]**.

‡- symbol for **manual mode** is blinking and measured value for the inserted block distance is shown.




**Move down sensing weight**

↓ - symbol for moving down  
Measured value indicates the tape length run out from flange bottom line to sensing weight bottom line depending on selected length unit [083] (m, ft, in) and selected decimal places [062].

001 empty calibration

m / ft / in



**Move up sensing weight**

↑ - symbol for moving up  
Measured value indicates the tape length run out from flange bottom line to sensing weight bottom line depending on selected length unit [083] (m, ft, in) and selected decimal places [062].




The loose band switch and the upper limit switch are **out of order** during manual mode operation!

- ▶ Therefore it is possible in the manual mode to lower the sensing weight into improper areas of the silo/bunker or into the discharge section!
- ▶ Please make sure that you know the position in which the sensing weight is currently located.


During manual mode operation the last valid measured value remains saved internally, it is not overwritten in manual mode. The outputs still follow this.  
(e.g. with a 50% fill level, 12 mA is still output for the current output)

Once work in manual mode has been completed, the measured value display [000] is changed back to the form of depiction originally selected! (e.g. fill level in technical units TE)

- ▶ If the height of the silo is not exactly known, the empty calibration [001] could be determined with the help of the manual mode.



## Simulation - parameter P 026



Select simulation.



Default value sim. off (simulation off)

Insert simulation value


|                 |              |                |
|-----------------|--------------|----------------|
| Range of values | sim. level   | 0 ... 99 m     |
|                 | sim. volume  | 0 ... 100.000  |
|                 | sim. current | 0 ... 22.00 mA |

## Example for simulation level

Settings at LF20



## Current output - parameter P 033



Please note selection.



Select current range.

Default value      4 ... 20 mA


033 current range

- 4 ... 20 mA
- 0 ... 20 mA

The characteristics of the current output can be influenced using the parameter level/volume [050] as follows.



## Output on alarm - Parameter P 040



Please note selection.

Select current output.

Default value MIN (0/3.6 mA)

|   |
|---|
| <b>040 output on alarm</b>              |
| <input type="checkbox"/> MIN (0/3.6 mA) |
| <input type="checkbox"/> MAX (22 mA)    |
| <input type="checkbox"/> hold           |
| <input type="checkbox"/> user-specific  |

These parameters determine the characteristics of the current output in the event of an error.

Selection At the current output

MIN (0/3.6mA) the current falls to 0 mA or 3,6 mA  
(depending on parameter **current range [033]**)

MAX (22mA) the current increases to 22 mA.

hold the last current output is retained.

user-specific the current set in **output on alarm [041]** is output.

Please note setup value.


Insert output on alarm.

Default value 3,60 mA

|                            |
|----------------------------|
| <b>041 output on alarm</b> |
| _____ mA                   |

Range of values 0 ... 22,00 mA

## Safety distance - parameter P 042




Insert safety distance.

Default value 0 m

Range of values 0 m ... MS

This parameter prevents the sensing weight from running out into improper areas of the silo/bunker or into the discharge section.



Select signal type.


Default value alarm

045 in safety distance

- alarm
- warning

This parameter determine the device reaction, in case the sensing weight reaches the **safety distance [042]**.

## Security distance - parameter P 043



Please note setup value.

|                       |
|-----------------------|
| 043 security distance |
| [083]                 |

Please note selection.

|                                  |
|----------------------------------|
| 044 in security dist.            |
| <input type="checkbox"/> warning |
| <input type="checkbox"/> alarm   |

This parameter determine the device reaction, in case the sensing weight reaches the **security distance [043]**.

## Linearisation - parameter group PG 05

PG 05+  
page LF-PA-04

|              |                          |
|--------------|--------------------------|
| level/volume | 050                      |
| /level CU    |                          |
| level DU     | <input type="checkbox"/> |
| ullage CU    | <input type="checkbox"/> |
| ullage DU    | <input type="checkbox"/> |

**E** **[ ]** **[ ]**



**[ ]**  
[ ]  
[ ]

Please note selection.

Select display value in the measured value display parameter [000].

Default value      level CU

|                          |              |
|--------------------------|--------------|
| 050                      | level/volume |
| <input type="checkbox"/> | level CU     |
| <input type="checkbox"/> | level DU     |
| <input type="checkbox"/> | ullage CU    |
| <input type="checkbox"/> | ullage DU    |



<sup>1)</sup> Dimension unit according selected parameter **customer unit** [056] see below

<sup>2)</sup> Dimension unit according selected parameter **distance unit** [083] see page **LF-PA-22**

**E** **[ ]** **[ ]**

|               |                          |
|---------------|--------------------------|
| customer unit | 056                      |
| /kg           |                          |
| t             | <input type="checkbox"/> |
| m³            | <input type="checkbox"/> |
| ft³           | <input type="checkbox"/> |
| m             | <input type="checkbox"/> |
| ft            | <input type="checkbox"/> |
| in            | <input type="checkbox"/> |

**[ ]**  
[ ]  
[ ]

Select customer unit (dimension unit) for CU.

Default value      %

► active only with selection CU,  
no function with selection DU

|                          |               |
|--------------------------|---------------|
| 056                      | customer unit |
| <input type="checkbox"/> | %             |
| <input type="checkbox"/> | ft³           |
| <input type="checkbox"/> | kg            |
| <input type="checkbox"/> | m             |
| <input type="checkbox"/> | ft            |
| <input type="checkbox"/> | m³            |
| <input type="checkbox"/> | in            |

**E** **[ ]** **[ ]**

|            |                      |
|------------|----------------------|
| max. scale | 057                  |
| 100,00 x   | <input type="text"/> |

**[ ]**  
[ ]  
[ ]

Please note setup value.

Inset the maximum scale value of measurement.

In the dimension unit selected and the number of decimal places selected.

Default value      100


Range of values      1 ... 100000

|       |            |
|-------|------------|
| 057   | max. scale |
| _____ | [056]      |

Return to  
Group selection

page LF-PA-04

## Display - parameter group PG 06+



### Select language

Default value English

#### 060 language

- Englisch
- Deutsch
- Français
- Japanisch

### Insert time until return to measured value display [000].

Default value 100 s (seconds)

#### 061 back to home

\_\_\_\_\_ s

### Select number of decimals.

For display measured value [000] and input parameters.


Default value x.xx (two decimals)

#### 062 no. of decimals

- X
- X,X
- X,XX
- X,XXX

### Select „on“ for display check.


All points on the display are activated for around two seconds.



Default value off

Switches automatically to „off“ after this 2 seconds.

## Diagnostics - parameter group PG 07+



### An error occurring in the device is shown

- by the error symbol in the display measured value [000]
- warning the device continues to measure
- alarm permanent
- with relay output. The relay switch, if for the parameter(s) **relay 1 [014]** and/or **relay 2 [01A]** and/or optional **relay 3 [01B]** and/or **relay 4 [01C]** the function **alarm** has(have) been selected.
- via the current output. The current output takes the value that has been determined in **output on alarm [040]**.
- in the parameter group diagnostics [07] with the code **[W] warning** and **[A] alarm** in parameter **present error [070]** respectively in **previous error [071]**

► Only the error with the highest level priority is shown.

### Present error is shown.

|            |  |
|------------|--|
| Letter     | <b>W</b> = warning<br><b>A</b> = alarm |
| Error code | <b>621</b> (example)                   |

► Warning **[W]** is shown.

► Alarm **[A]** is shown and additional a relay output switches, if the function **alarm** is selected and current output alters.

### Previous error is shown.

|            |  |
|------------|--|
| Letter     | <b>W</b> = warning<br><b>A</b> = alarm |
| Error code | <b>440</b> (example)                   |

► You will find the depiction of all error codes on page **LF-PA-21**.

### Deletion of errors.

|               |             |
|---------------|-------------|
| Default value | <b>keep</b> |
|---------------|-------------|

### Reset all parameters to default values.

|                 |  |
|-----------------|--|
| Default value   | <b>0</b>   |
| Range of values | < > 333 (does not undertake reset)<br>333 undertakes reset |

► At least a basic setup is required after the reset.

### Lock of parameter entries.

|                 |                                      |
|-----------------|--------------------------------------|
| Default value   | <b>100</b> (unlocks parameter entry) |
| Range of values | < > 100 (locks parameter entry)      |


**074 unlock parameter**

Note unlock parameter.

## Error messages Reason and corrective action

| Code         | Reason  | Corrective action  |
|--------------|---|--|
| A100         | Checksum error in internal program memory                   |  |
| A101         | Checksum error in EEPROM 1                                  |  |
| A102         | Checksum error in EEPROM 2                                  |  |
| A103         | Initialisation failed                                       | - Reset<br>- Avoid EMC problems<br>- If the alarm is still present after a reset, contact service and/or replace the electronics |
| A106         | Program download error (only for service technicians)       | - Repeat download and/or restart   |
| A110         | Default service parameter loaded                            |  |
| A111         | Default customer parameter loaded                           | - Warning that a reset has been undertaken<br>- Disappears automatically with the next entry                                     |
| A112         | Default input/output configuration loaded                   |  |
| A120         | Error during loading the service parameters                 |  |
| A121         | Error during loading the customer parameters                |  |
| A122         | Error when loading the input/output configuration           |  |
| A123         | Error during loading the last measured values               |  |
| A125         | Error during loading the language string                    |  |
| A130         | Process of saving the service parameters has failed         |  |
| A131         | Process of saving the customer parameters has failed        |  |
| A132         | Process of saving the input/output configuration has failed |  |
| A133         | Process of saving the measured values has failed            |  |
| A200         | Interface to motor controller defective                     |  |
| A201         | Initialisation of motor controller failed                   |  |
| A202         | Fatal motor error   |  |
| A203         | Temperature inside the motor driver is too high             | - Reset or contact service and/or replace the electronics, if the alarm is still present after the reset                         |
| A205         | Motor current consumption is too high                       | - Avoid excessive heating of the device  |
| A206         | Motor driver defective                                      | - Reset<br>- If the alarm is still present after a reset, contact service and/or replace the electronics                         |
| A220         | Temperature in the device is too high                       | - Check mounting position and /or time interval [021]<br>- If the alarm is still present after a reset, contact service          |
| A330         | Maximum time for a measurement cycle exceeded               | - If the alarm is still present after several measurement processes, contact service   |
| A340         | Sensing weight or tape / rope is torn                       | - Inspection of the sensing weight and measuring tape<br>- If necessary, replace sensing weight and /or measuring tape           |
| A350         | Sensing weight is buried                                    | - Expose sensing weight by hand<br>- Reset or briefly cutting off the supply voltage (restart of the device)                     |
| A430         | Tape-switch expected  | - Contact service and / or replace tape  |
| A431         | Limit-switch expected                                       | - Contact service  |
| A440         | Minimum move distance not reached                           | - Check mounting position<br>- Remove transportation lock<br>- Observe minimum sensing weight move distance of 0,2 m             |
| A450         | Time for counting wheel pulses exceeded                     | - Check of counting wheel<br>- Reset   |
| A460         | Counting wheel is slipping                                  | - If the alarm is still present after several measurement processes, contact service   |
| A470         | Measurement could not be started                            | - Check the device for damage or blocking parts  |
| W621         | Simulation activated  | - Deactivate simulation in parameter [026]   |
| A630         | Maximum move distance exceeded                              | - Check the tape switch<br>- Check mounting position<br>- Use device with larger measurement range                               |
| A650<br>W651 | Security distance underrun                                  |  |
| A660<br>W661 | Safety distance underrun                                    | - Check mounting position<br>- Check the parameterisation  |
| W681         | Measurement range exceeded                                  |  |
| W700         | Tape / rope change required                                 | - Check measuring tape and replace if necessary<br>- Reset maintenance interval counter  |

## System parameters - parameter group PG 08→



Please note setup values.

Insert name of measuring point.

080 tag number

Default value -----

Range of values 16 alpha-numerical digits

Protocol- and software version is shown here.

081 protocol+sw-no.

Serial number of the device is shown here.  
It is identical with the number on the type-plate.

082 serial number

Please note selection.

Select distance unit.

It forms the basis for all display and entry values, with exception of the customer unit (CU), in case this has been selected.

083 distance unit

- m
- ft
- in

Default value m (meter)